

Frontier Place RainBird Irrigation System

Description:

The whole system is 4 zones including on for roof evaporation spray (Zone 4).

3 zones are for grass & area irrigation. A RainBird ESP-LX MODULAR Controller runs up to 4 programs (A,B,C & D) where zones can be mixed and times can be set.

2015 we had a new pump (above ground) and system installed by Greenscape Irrigation Inc. (Randy Cramer O.403-255-6396 & Jon Barbeau M.403-809-0328)

Below is a layout of zones.



To turn a zone on and run manually, follow these instructions:

1. Turn dial to “MANUAL WATERING”
2. Select on LED the zone you want to run
3. Press “NEXT” to set time (12 hrs Max)
4. Return dial to “AUTO”

The manual zone will finish running and then return to the regularly scheduled programming...

